
Lifetime Degradation in Multicrystalline Silicon under Illumination at Elevated Temperature: The Role of Hydrogen

Dennis Bredemeier¹, Dominic C. Walter¹, and Jan Schmidt^{1,2}

¹ Institute for Solar Energy Research Hamelin (ISFH), Germany

² Department of Solar Energy, Institute of Solid State Physics, Leibniz Universität Hannover, Germany





Impact on the degradation extent: Passivation schemes, phosphorus diffusion and fast firing

0.10

0.08

0.06

0.04

0.02

0.00 0

Effective defect


with phosphorus


.....

0.01 0.1

diffusion

- LeTID degradation extent 20 times more pronounced on Al₂O₃/SiN_x-stack passivated samples than on samples with Al₂O₃ single-layers.
- Our SiN_x layers contain ≈12-20 at.% hydrogen and the Al₂O₃ single-layers contain ≈1-2 at.% hydrogen.
- Hydrogen from SiN, layers diffuses into the silicon bulk during the high-temperature firing step.
- Maximum defect density increases approx. exponentially with increasing peak firing temperature
- Indication for hydrogen playing a major role in the LeTID ≻ effect
- Samples that received a phosphorus diffusion show a less pronounced degradation than samples with no phosphorus diffusion
- Significant decrease of metal contaminants in the silicon bulk by phosphorus diffusion due to segregation gettering
- Grain boundaries appear brighter in a PL image and are less affected by the degradation than the intra-grain area, because of metal gettering by grain boundaries.
- Indication for a metal impurity being involved in the LeTID ≻ effect





Enlarged section of a PL image of a fully degraded mc-Si sample. The arrows point towards grain boundaries in the mc-Si material, which appear brighter in the PL image than the PL signal within the grains.

1 Exposure time t [h]

10 100 1000

Conclusions

- LeTID strongly depends on the applied passivation scheme with pronounced degradation only observed for hydrogen-rich passivation layers such as SiN_x (cf. [5]).
- A phosphorus gettering step significantly decreases the degradation extent in comparison to a non-diffused sample (cf. [6])
- The degradation extent increases approx. exponentially with increasing peak firing temperature
- Metal-hydrogen complexes are strong candidates for the root cause of LeTID

References and Acknowledgments

Ramspeck et al., in Proceedings of the 27th European Photovoltaic Solar Energy Conference (WIP, Munich, 2012), p.861.

- [2] Kersten et al., Sol. Energ. Mat. Sol. Cells. 142, 83 (2015).
- [3] Nakayashiki et al., IEEE J. Photovolt. 6, 860 (2016).
- [4] Bredemeier et al., AIP Adv. 6, 035119 (2016). [5] Kersten et al., Energy Procedia 92, 828 (2016).
- [6] Zuschlag et al., Prog. Photovolt: Res. Appl. 25, 545 (2016).

This work was funded by the German State of Lower Saxony and the German Federal Inistry of Economics and Energy and by industry partners within the research project LIMES (Contract no. 0324204D). The content is the responsibility of the authors.

Institute for Solar Energy Research Hamelin (ISFH)

Am Ohrberg 1, D-31860 Emmerthal, Germany, Tel.: +49 (0) 5151 999-100, Fax: +49 (0) 5151 999-400